

TIPS OF THE TRADE

SPRAY ULTRA HIGH BUILD (UHB) COATINGS EASIER



Ultimately, the best solution for spraying Ultra High Build coatings is a plural component sprayer.

Should, however, UHB coating have to be sprayed with standard single-leg machines, the following 12 tips will help ensure a successful job:

1. Select the right size pump
2. Gravity feed material
3. Use the correct size filter
4. Pump coating within the correct temperature range
5. Use correct size airless hose
6. Use the correct gun
7. Use the correct size tip
8. Heat coating with extreme care
9. Use a high 'cut' solvent
10. Clean the entire system thoroughly at the end of your shift
11. Clean hopper of previous batch of material before filling with new batch
12. Flush pump throughout shift

